



OPERATING INSTRUCTIONS

Opening Unit

Press on the latch switch on the bottom part and lift the top half of the unit.

Charging AA rechargeable batteries

Insert AA rechargeable batteries into the cavity according to the orientation engraved at the bottom of charge cavities. Average charge time is approx. 4 hrs per AA battery (based on 500 mAmp capacity). Adjust the charge time according to your battery capacity. Charge times will vary depending upon the strength of sunlight or the depth of discharge of the batteries. For best results, recharge batteries at the first sign of weakness except for nicad batteries which require full discharge. To maximize charging rate, position the solar panel using the positioning tab towards the sun. NOTE: THIS UNIT WILL NOT CHARGE ALKALINE BATTERIES BUT CAN RECHARGE MOST "RECHARGEABLE" ALKALINE BATTERIES.

Additional Storage Cavities

Additional storage cavities have been integrated into this unit to permit storage of up to 4 additional batteries. Batteries will NOT be charged in those cavities.

INSTRUCTIONS

Ouverture de l'appareil

Appuyez vers l'intérieur sur le loquet situé au bas de l'appareil et soulevez la partie supérieure de l'appareil.

Pour charger des batteries AA rechargeables

Insérez des batteries AA rechargeables en respectant l'orientation gravée au bas du compartiment. Le temps de charge est d'environ 4 heures par batterie AA (pour une capacité de 500 mA). Ajustez le temps de charge en fonction de la capacité des batteries. Le temps de charge variera également en fonction de l'ensoleillement et du niveau de charge des batteries. Pour de meilleurs résultats, rechargez les batteries au premier signe de faiblesse; excepté pour les batteries nicad qui requièrent une décharge complète. Afin de maximiser la recharge, positionnez le panneau solaire en orientant vers le soleil la languette de positionnement. REMARQUE: CET APPAREIL NE PEUT PAS CHARGER LES PILES ALCALINES MAIS PEUT RECHARGER LES NOUVELLES BATTERIES ALCALINES RECHARGEABLES.

Compartiments de rangement supplémentaires

Cet appareil possède des compartiments permettant de ranger jusqu'à 4 batteries supplémentaires. Les batteries NE CHARGENT PAS lorsqu'on les place dans ces compartiments.