



BRUNTON
© LITE-TECH
Penscope

TO USE YOUR PENSCOPE AS A TELESCOPE:

1. Hold the penscope with both hands - one around the focus wheel and one around the objective lens end. This will ensure the most steady view.
2. Rotate the focus wheel clockwise for objects further away. Rotate the focus wheel counterclockwise for objects which are closer to you.

TO USE YOUR PENSCOPE AS A MICROSCOPE:

1. Couple the microscope adapter to the penscope by pushing the adapter over the objective lens end of the penscope.
2. Hold the penscope with both hands similar to the telescope instructions above.
3. Hold the penscope about 2" above the object you are inspecting. This distance may vary by $\pm 1/4$ " as each individual is slightly different.
4. Move the penscope up and down very slowly until you reach the ideal distance where you can see the object you want to inspect.
5. To achieve the sharpest image, you may have to rotate the focus wheel slowly in either direction.

MAINTENANCE

1. Remove dust and dirt with a lens/optics cleaning kit or a soft cloth.
2. Always store your penscope in the carrying case .
3. Never disassemble the penscope.

WARRANTY

The Lite-Tech™ Penscope comes with a one year limited warranty against defects in workmanship and materials to the original owner.

THE BRUNTON CO.

620 East Monroe
Riverton, WY 82501
ph:307.856.6559

Canada ph: 705.749.9327
email: support@brunton.com
web: brunton.com